


DIAGNOSTIC CHARACTERIZATION OF BATTERY ELECTRODES



presented by

Frank McLarnon



**Lawrence Berkeley National Laboratory
Berkeley, California 94720**

US – China Electric Vehicle and Battery Technology Workshop

August 31, 2010

Li-Sn Reference Electrode Cell Measurements

- Measurements in cells with Li-Sn reference electrodes help quantify contributions of positive and negative electrodes to cell impedance and impedance rise during cycling and aging
- Full cell data show that electrolyte salt has a significant effect on cell impedance: $\text{LiBOB} > \text{LiBF}_4 > \text{LiF}_2\text{OB} > \text{LiPF}_6$
- The negative electrode is more affected by electrolyte salt than the positive electrode
- Other data indicate that the electrolyte salt has a strong influence of SEI properties





Surface Electronic Conductance Sensing AFM





Topography

Conductance




5 x 5 μm images







Fresh cell

Cycled cell



Topography


Conductance




- Scanning probe microscope with an electronically conducting tip detects local electrode morphology and surface electronic conductance
- Identified changes in electrode surface morphology, surface chemistry, and SEI thickness that accompanied cell cycling

Raman Microscopy of Composite Electrodes


- Raman microscopy detects frequency shift of light scattered from an electrode
 - Probes local structure and composition
- Raman images show graphite, carbon black, and metal oxide distribution
- Revealed significant surface composition changes during cycling
- Identified carbon redistribution as a contributor to Li-ion cell power fade




10 μm



Cathode from cycled cell




Optical image




Fresh cathode


Raman Microscopy: Electrode Structure



Fresh graphitic anode




480 cycles, 20°C, 33% Q_{rev} loss




140 cycles, 60°C, 65% Q_{rev} loss

- Specific Raman shifts are characteristic of disordered (D) and graphitic (G) forms of carbon
- Raman images of local D/G ratios identify areas where the original graphitic structure degraded due to cell cycling
- Identified graphite surface degradation as a contributor to cell capacity fade




Infrared Spectroscopy

- Fast, simple, and sensitive to all components regardless of crystallinity
- Qualitative and quantitative analysis
- Sensitive to local coordination and oxidation state




Overcharge products identified



Spectrum changes with substitution


Spectrum changes with oxidation state



G. Chen and T. J. Richardson, *J. Electrochem. Soc.*, **156**, A756-A762 (2009).

Transmission Electron Microscopy (TEM)


- A thin sample is bombarded with a highly focused electron beam: images and diffraction patterns are formed by interaction of these electrons with the atomic constituents in the sample
- Analysis of TEM images and diffraction patterns yields information on the sample crystal structure and defects that are present



Li_2MnO_3 image showing Li ordering in transition metal (TM) planes. Li columns (dark) are surrounded by Mn columns (bright)


D. Abraham, ANL

Ni-O-Li-O-Ni
(ordered rock salt)





Particle Bulk

Li_xNiO formation on $\text{LiNi}_{0.8}\text{Co}_{0.2}\text{O}_2$ particles during cell aging degrades positive electrode performance




Ni-O-Ni-O-Ni
(rock salt)




Particle Surface


Transmission Electron Microscopy



Detailed structural imaging




Electron diffraction
identifies phases




High-resolution TEM
shows phase boundary

G. Chen, X. Song, and T. J. Richardson, *Electrochemical and Solid State Letters*, **9**, A295 (2006).






Identification of charge-discharge mechanisms

X-Ray Diffraction



- Qualitative and quantitative analysis of crystalline phases
- Particle size and shape information
- High spatial resolution with small beam sizes

Particle isolation in cathodes following high-temperature storage




G. V. Zhuang, G. Chen, J. Shim, X. Song, P. N. Ross, and T. J. Richardson, *J. Power Sources* **134**, 293-297 (2004).

Charge distribution in cycled electrodes

J. Liu, M. Kunz, K. Chen, N. Tamura, and T. J. Richardson, *Journal of Physical Chemistry Letters*, **1** (2010) 2120-2123.


X-ray Photoelectron Spectroscopy (XPS)

- Monoenergetic X-rays eject photoelectrons from a sample, and binding energies of the ejected photoelectrons provide information on sample elemental composition and chemical state
- Well suited for surface analysis of electrode samples




Changes in positive electrode surface film composition and morphology are partially responsible for cell impedance rise

Graphite electrode SEI composition and morphology changes can cause cell capacity fade and impedance rise



Secondary Ion mass Spectrometry (SIMS)

- Secondary ions ejected from a sample during bombardment by high-energy primary ions are accelerated into a mass spectrometer, where they are separated according to their mass-to-charge ratio and counted
- Secondary-ion data in static SIMS mode identify composition of the electrode surface (1 - 2 monolayers)
- Dynamic SIMS data reveal electrode composition and trace impurity content as a function of sputtering time (depth)
- Identified transition metal (Mn, Ni, Co) accumulation on graphite electrodes as a catalyst for SEI layer changes that degrade Li-ion cell performance



Dynamic SIMS data on graphite negative electrode