

# TG-1: Portable Instrument for Transient Particulate Matter Measurements

S. Gupta, G. Hillman, J. Shih, R. Sekar  
ARGONNE NATIONAL LABORATORY

Russel R. Graze  
CATERPILLAR, INC.

Shirish Shimpi, William T. Martin  
CUMMINS, INC.

Del Pier  
SIERRA INSTRUMENTS, INC.

Contract manager: Gurpreet Singh, DOE-OFCVT





# Overview

- Current particulate matter measurement issues
- Survey of commercially available instrumentation
- Laser-induced Incandescence
- Instrument development
- Future efforts




# Emission Regulations Have Rendered PM Emissions So Low as to Be Comparable to Minimum Instrument Detectivity

Description	System Details	MC (mg/m <sup>3</sup> )
N. J. Khatri, John Johnson (1978)	1973 Caterpillar 3150, V-8	27-84
Dave Hoefeldt (1993)	2 cyl Kubota generator set	2-25
Abdul Khalek (1998)	Perkins 4-cylinder	0.4-14
(2003)	Caterpillar's recommendation	0.1 target



# Heavy-duty Truck Emissions Regulated Based on a Transient Cycle as Well as Steady-state Modes

EPA heavy-duty engine dynamometer transient cycle



Time response  $\leq 0.5$  sec

Dynamic range  $\sim 3$ -4 orders of magnitude

target



# Health Effects Render Particle Size and Number Emissions Important

- Future (EU) regulations are likely to be based on particle number and size.
  - Aggregate particle size ( $D$ ) and number density ( $N$ ) measurement capability desirable



# A Survey of Available Transient PM Measurement Instrumentation

Instrument	Issues	Cost (Thousands)
Smoke meters	Quantitative measurements not possible	~\$100
TEOM 1105	Yields -ve measurements, vibration sensitive, and coarse resolution	\$24
ELPI	Very coarse resolution	\$70
DMS 500 (Cambustion)	Very expensive	\$190
TG-1 (Argonne)	portable, cross-platform, real-time and modular	\$30





# Tapered Element Oscillating Microbalance (TEOM)


## Tapered Element Oscillating Microbalance

Measures Mass Concentration,  $M$  (g/cc) in Diesel Exhausts

$$M = \frac{k_o}{f^2}$$

$$MC = \frac{1}{V} \frac{dM}{dt} = \frac{1 - 2k_o}{V f^3} \left( \frac{df}{dt} \right)$$


$\therefore f$  as well as  $\frac{df}{dt}$  need to be measured accurately.





# Measurement Issues with TEOM

- Sensitive to typical test-cell vibration levels
- Can yield negative measurements due to water vapor desorption



SAE  
2001-01-3575



# Laser-Induced Incandescence (LII)



# LII Has Many Desirable Characteristics

- Primarily measures volume fraction

$$f_v \times \rho = MC \text{ (grams/cc)}$$

Minimum detectivity = 0.001 (mg/m<sup>3</sup>)

- Can measure in real-time

Time response/ resolution = 1e-9 sec/ 0.1 sec


- In combination with Rayleigh scattering yields

Mean particle size (nm)  $D = K_1 \cdot \left( \frac{Q_{vv}}{MC} \right)^{1/3}$


Number density (#/cc)  $N = K_2 \cdot \frac{MC}{D}$

# LII Phenomenon

Particle heating by means of a highly energetic laser pulse



Detection of the enhanced thermal radiation





$$\underbrace{Q_{abs} \cdot \frac{\pi d_p^2}{4} \cdot E_l}_{Absorption} - \underbrace{\Lambda \cdot (T - T_0) \cdot \pi d_p^2}_{Heat\ conduction} + \underbrace{\frac{\Delta H_v}{M} \cdot \frac{dm}{dt}}_{Vaporization} - \underbrace{\pi d_p^2 \int \epsilon(d_p, \lambda) M_2^b(T, \lambda) \cdot d\lambda}_{Thermal\ radiation} - \underbrace{\frac{\pi d_p^3}{6} \rho_s \cdot C_s \cdot \frac{dT}{dt}}_{Change\ of\ internal\ energy} = 0$$



# Development of an LII-Based Instrument


# Many Possible Arrangements Were Evaluated...



- Sensor head design dependent on engine size
- Potential operator (laser) safety hazard



# ...to Reach an Optimal Design





# A Portable Instrument Was Integrated

Component cost: \$40 K

Size: 24" x 15" x 8.5"

Weight: Approx 40 lbs

## Specifications

10 Hz sampling

## Utility requirements

110 VAC, 13 Amps



Patent pending



# Performance Tests on a Light-Duty Diesel Engine



Mercedes Benz



1.7 L

4 cyl

Low-inertia  
Dynamometer



# Excellent Performance over Typical Diesel Engine Steady-State Operation




S. Gupta et al.; 6<sup>th</sup> ETH Conference on Nanoparticle Measurement




# TG-1 Has Better Time Resolution than a TEOM 1105

## TEOM 1105



5 sec mvg. average



## TG-1



0.3 sec mvg. average




# TG-1 Performs Better than a TEOM 1105 for Step Changes in Engine Modes



Transient measurements performed on a Mercedes Benz 1.7 L engine coupled to a low-inertia dynamometer



# TG-1 Performance over the Urban Driving Cycle





# Performance Tests on a Heavy-Duty Diesel Engine



CAT C-10

6 cyl

10 L


1800 rpm

1460 Nm@

1200 rpm




# Validation Using Sierra's BG2 Dilution System



➤ Such a setup necessitated the use of dilution ratios ~ 4 – 8




# TG-1 Has Excellent Day-to-day Repeatability





# EPA Heavy-Duty Engine Dynamometer Transient Cycle






# Tests on Cummins Full-Flow Dilution Tunnel






# The Engine Tested Had to Satisfy the Most Stringent of PM Emission Standards





# Cummins' Full-Flow Dilution Set-Up





# Gravimetric vs. TG-1 over the Transient Cycle


	Total flow (m3)	Gravimetric (mg)	TG-1 (mg)
Cold start	1.1646	1.17	1.285
Hot start 1	1.1684	1.15	1.385
Hot start 2	1.16294	1.158	1.428
Hot start 3	1.16334	1.194	1.416



- In these limited set of tests, the agreement is encouraging.
- Cummins desires agreement within **0.01 mg**




# Ongoing Effort: Develop Capability to Measure Particle Number Density and Aggregate Size




Rayleigh scattering signal in combination with LII signal provides aggregate particle size and number information

# Particle Size to be Validated with TEM Morphology Studies




- Stretched chain-like particles
- 17,000 magnification




K. O. Lee, poster session



# Such Studies Yield Very Accurate Particle Size Information



Primary particle size



Aggregate particle size



# TG-1 May Help Develop Control Strategies to Lower the NO<sub>x</sub>–Soot Trade-Off

